


Dismantled

Missing motor / solenoid




Broken housing / casting


Core acceptance criteria EGR Valves: Rejected

Rejected


1. Cores must be returned in the original box.
2. Protecting items (caps, covers, foam protectors etc.) must be installed on the core in the same way as they were installed on the remanufactured part.
3. Please view more details on our core acceptance criteria on our homepage.



Component missing



Cracked or damaged plastic parts



Cooler missing

Core acceptance criteria EGR Valves: Reduced

Reduced

1. Cores must be returned in the original box.
2. Protecting items (caps, covers, foam protectors etc.) must be installed on the core in the same way as they were installed on the remanufactured part.
3. Please view more details on our core acceptance criteria on our homepage.